Anchors

001

PC 4540 Fu	ıll Threa	nd V	Wedge Anchors			Zinc Plated	
Cat. No.	UPC	Anchor Hole Dia.	O.A. Length	Thread Length	Unit	Std.	
W14 134	59300	1/4"	1-3/4"	3/4"	100	1000	
W14 214	59302	1/4"	2-1/4"	1-1/4"	100	1000	
W14 314	59304	1/4"	3-1/4"	2-1/4"	100	1000	
W38 214	59306	3/8"	2-1/4"	1-1/8"	100	1000	
W38 234	59307	3/8"	2-3/4"	1-5/8"	100	500	
W38 300	59308	3/8"	3"	1-7/8"	100	500	
W38 334	59310	3/8"	3-3/4"	2-5/8"	100	500	
W38 500	59311	3/8"	5"	2-1/2"	50	250	
W12 234	59312	1/2"	2-3/4"	1-1/4"	50	250	
W12 334	59313	1/2"	3-3/4"	2-1/4"	50	250	
W12 400	59314	1/2"	4-1/4"	1-1/2"	50	250	
W12 512	59316	1/2"	5-1/2"	1-1/2"	25	250	
		Other D	Diameters ar	d Lengths	Available.		

_

PC 4310 Stainless Steel			Wedge Anchors			Full Thread	
Cat. No.	UPC	Anchor Hole Dia.	O.A. Length	Thread Length	Unit	Std.	
WS14 134	70310	1/4"	1-3/4"	3/4"	100	1000	
WS14 214	70312	1/4"	2-1/4"	1-1/4"	100	1000	
WS14 314	70314	1/4"	3-1/4"	2-1/4"	100	1000	
WS38 214	70320	3/8"	2-1/4"	1-1/8"	100	1000	
WS38 234	70322	3/8"	2-3/4"	1-5/8"	100	500	
WS38 300	70324	3/8"	3"	1-7/8"	100	500	
WS38 334	70326	3/8"	3-3/4"	2-5/8"	100	500	
WS38 500	70328	3/8"	5"	2-1/2"	50	250	
WS12 234	70340	1/2"	2-3/4"	1-1/4"	50	250	
WS12 334	70342	1/2"	3-3/4"	2-1/4"	50	250	
WS12 400	70344	1/2"	4-1/4"	1-1/2"	50	250	
WS12 512	70346	1/2"	5-1/2"	1-1/2"	25	250	

Special Order Non-Returnable

Great for Strut!

PC 4545 NEW

Wedge Anchor Driver

Cat. No.	UPC	Description	Unit	Std.
WAD 14	10514	1/4" Installation Tool	1	12
WAD 38	10538	3/8" Installation Tool	1	12
WAD 12	10512	· 1/2" Installation Tool	1	12

Case hardened tool drives in wedge anchors quickly without deforming the anchor or nut. Gets into hard to reach areas such as channel, strut, panels or cabinets by providing that extra few inches.

No More Stripped Threads or Damaged Nuts!

Dottie's wedge anchor tool will save you time and money. If you ever had to remove a damaged anchor, you'll appreciate Dottie's Wedge Anchor Tool. Simply screw the anchor into the tool to the desired thread depth, set it and WAK-IT! Remove the tool by unthreading it, and leave yourself a perfect anchor to work with—every time. Remember to wear eye protection see page E12.

